



Title: C:\Documents and Settings\woode\Desktop\New Folder\44921.dwg



Title: C:\Documents and Settings\woode\Desktop\New Folder\80128851.DWG




NOTES:

- 1. REMOVE ALL BURRS AND SHARP EDGES, .010 MAX.
- 2. PART TO BE CLEAN.


D AS THE BASS FOR THE MANUFACTURE OR 1000 ± 0,000

SMITH & NEPHEW, INC ENDOSCOPY DIVISION, MANSFIELD, MA ENDOSCOPY DIVISION, MANSFIELD, MA BODY, EXTENDER C MANSTON SMITH SMITH & NEW	INC. ED, MA		B	Srt_10r_1
SMITH ENDOSC C C C C C C C C C C C C C C C C C C C	4 & NEPHEW	BODY, EXTENDER	8013158	NOT SCALE DRAWING
	SMIT	je ,	J V	2:1 D

Title: C:\Documents and Settings\woode\Desktop\New Folder\80131581.DWG



Title: C:\Documents and Settings\woode\Desktop\New Folder\81073691.DWG



Title: C:\Documents and Settings\woode\Desktop\New Folder\80073891.DWG